



**NOTES:**

A variety of #10 fasteners is included in the hardware pack. Select the correct fasteners for the door and frame materials involved. For wood or hollow metal doors use self-tapping sheet metal screws; for reinforced or heavy gauge metal doors and frames, use machine screws.

**OVERALL DIMENSIONS:**  
 TJ MOUNTING PLATE  
 12 1/2" L x 2" H x 1/4" THICK  
 LOWER TJ BRACKET  
 4 3/4" L x 2 3/4" H x 1/4" THICK

DRAWN BY: TG	DATE: 04-01
CHKD BY:	
APP'D BY:	

TITLE	351+TJ51 DOOR AND FRAME PREP
-------	---------------------------------



FIRM NO.	351+TJ_TMP
----------	------------

REV.	B
	04-01